

TECHNICAL DATA SHEET

Neutralize Cidex® with Glycine G36050

Procedure:

1. Add 25 grams of Glycine (G36050-100.0) to each gallon of Cidex®.
2. Wait one hour to fully neutralize solution.
3. Discard residual solution into drain.
4. Flush drain thoroughly with water.

Note: If using a Tablespoon (12.3g) we recommend adding 2 heaping tablespoons of glycine to equal 25 grams